

Dear Valued Customer:

Your newly purchased vehicle has been equipped with a PassTime Elite product to help ensure that your payments are made as scheduled, otherwise your vehicle will cease to be operational.

This device can include an anti-theft system that may protect the vehicle from theft. Ask your dealer/lender for more information, as you may qualify for discounts on your comprehensive auto insurance. If using the anti-theft function, please contact your automotive insurance provider for further information.

Remember, it is your responsibility to make your payments on your scheduled due date. If your payment is not made, your vehicle will not operate.

Starting Instructions for the Anti-Theft Feature:

1. Put the key in the ignition and turn key to the "on or accessory" position.
2. Pause momentarily until you hear the Elite "double tone or chirp" start signal. You should then immediately start your vehicle.

If Your Vehicle Will Not Start:

1. Turn ignition key to the "off" position.
2. After 3 seconds you will hear a reset chirp. Follow the instructions above to start your vehicle.

If Your Vehicle Stalls:

1. Leave ignition key in the "on or accessory" position and restart your vehicle.
2. If the vehicle does not start, turn the ignition key off and follow the above instructions again.

Without the Elite Anti-Theft Feature:

There is not a starting procedure and you will start your vehicle as normal.



PassTime USA

Call Toll Free:
877-PASSTIME

Visit Us on the Web:
PassTimeUSA.com



Customer Operating Instructions

Congratulations on your newly purchased vehicle. Your vehicle has been equipped with one of the following PassTime Elite products:



PassTime Elite PLUS



PassTime Elite PRO

If you are not sure which Collateral Protection System has been installed in your vehicle, please contact your dealer/lender for further assistance.





Entering Codes Using the Black PassTime Remote:

1. After your dealer/lender has given you your 9-digit payment code, sitting in your vehicle, with the remote pointed at the dashboard, **TURN THE VEHICLE KEY TO THE "ON" POSITION** and press the PAY button and enter the code. Do this as soon as possible! You will hear a beep after each button is pressed.
2. After you enter your 9-digit payment code, the unit will respond with two identical positive tones. If the code was entered incorrectly or was not valid, the unit will respond with two different negative tones.
3. If you make a mistake entering the code, simply repeat Step 1.

Note: The TIME button will emit a series of individual beeps when pressed. By counting these beeps, each and every beep stands for an individual day left on the unit before your next payment is due.

Time To Make A Payment!

If you start your vehicle and hear a 20 second warning signal or alarm, you are near or past your scheduled car payment. Make your payment or contact your dealer/lender immediately! When the reminder signal sounds like a siren it means that this is your last day to make a payment before your vehicle becomes disabled. The Elite Plus device contains vehicle tracking technology which can and will be used to locate the vehicle.

Remote Button Features:

PAY Button: The PAY button must be pushed prior to entering your 9-digit payment code.

TIME Button: Press the TIME button **WHEN THE KEY IS IN THE ON POSITION AND THE CAR IS RUNNING** and (1) if your car payment is current the unit will beep once for every day available until you enter the Customer Reminder Period, or, (2) if you have entered the customer reminder period, the unit will beep once for each day that is available until your vehicle becomes disabled.

VALET Button: If your vehicle comes with the Anti-Theft feature, pressing the VALET Button **WHEN THE KEY IS IN THE ON POSITION AND THE CAR IS RUNNING** followed by entering four 0's (0000 is the default password), will turn the starting sequence or Anti-Theft feature off for up to 5 hours. To turn off the Valet Mode or reactivate the Anti-Theft feature, press the VALET Button again followed by 0000. The Valet Mode will automatically cease after 5 hours.



PASS Button: The PASS Button is used to enter or change the password used for the Valet Mode (see VALET Button). To enter or change the password, press the PASS Button **WHEN THE KEY IS IN THE ON POSITION AND THE CAR IS RUNNING** and first enter the current 4-digit password (i.e. 0000) and then enter a new 4-digit password of your choice (i.e. 1234) twice. The password would then be 1234.

The Elite Pro device installed in your vehicle will receive a wireless message after each payment is made to your dealer/ lender. The Elite Pro device will emit a positive confirmation tone upon starting the vehicle for the first time after receiving the new wireless message. Use the TIME button on your remote **WHEN THE KEY IS IN THE ON POSITION AND THE CAR IS RUNNING** to verify the number of days remaining before your vehicle is disabled. Remember, that if you do not make your payments, your car will not operate.

If you do not get a confirmation tone or your vehicle has been disabled contact your dealer/ lender immediately.

Time To Make A Payment!

If you start your vehicle and hear a 20 second warning signal or alarm, you are near or past your scheduled car payment. Make your payment or contact your dealer/lender immediately! When the reminder signal sounds like a siren it means that this is your last day to make a payment before your vehicle becomes disabled.

The Elite Pro device contains vehicle tracking technology which can and will be used to locate the vehicle.

If the Wireless Message is not received, contact your dealer/ lender and follow the instructions under Entering Codes Using the Black PassTime Remote listed under ELITE PLUS (Sect. 3).

If you are utilizing our Anti-Theft feature, please refer to the starting instructions in Sect. 2 of this brochure and the Remote Button Features listed in Sect. 3.

Emergency Code:

In the event of an emergency and your vehicle is disabled, call your dealer/lender if it is during business hours or use the 24-hour emergency code.

The code is 999 999. This will allow you to operate your vehicle for 24 hours.

Using your black PassTime remote, press 999 999. After 24 hours your vehicle will cease to be operational. You should hear a response or beep each time you press a button. This will give you 24 hours of additional operation. **DO NOT** press the PAY button before entering this code!

CONTACT YOUR DEALER/LENDER IMMEDIATELY:

Dealer/Lender: 9523
PassTime Acct # _____

(Dealer/Lender)
Toll Free IVR # _____

(Code by Phone) (855) 799-5884
Customer Acct # _____

Or call: (800) 865-3260

